

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

Item	Description	GMC	Auto Gear
	Upgrade/Service Kits		
	Bearing/Oilseal Kit		BK56
	Bearing/Oilseal Kit		BK56A
	Countershaft Gear Kit		13-86-410-006
	Countershaft Gear Kit		13-86-410-007
	Countershaft Gear Kit		13-86-410-008
	Countershaft Gear Kit		TNKT 1661
	Countershaft Gear Kit		TNKT 1781
	Overhaul Kit		OH56
	Overhaul Kit		OH56A
	Overhaul Kit		OH56B
	Shim Kit		SH56
	Small Parts Kit		SP56
	Small Parts Kit		SP56A
	Synchronizer Ring Kit		YN56
	Synchronizer Ring Kit		YN56A
	Synchronizer Ring Kit		YN56B
	Service Parts		
A1	Yoke Stop Snapping	1405 8965	10-00-139-031
A2	Speedometer Rotor	1252 3063	13-86-110-002
A2	Speedometer Rotor	1253 0271	13-52-110-013
A3	Speedometer Rotor Snapping	1405 8965	10-00-139-031
A4	Mainshaft Extension Bearing Assy	1252 3057	13-86-134-001
A5	Mainshaft Extension Bearing Washer	1245 5040	13-86-193-009
A6	Mainshaft Extension Brg/Shaft S'ring	1252 3253	13-86-139-001
A7	Mainshaft Extension Brg/Extension S'ring	1252 3058	13-86-139-005
A8	Mainshaft Reverse Gear Thrust Washer	1252 3053	13-86-193-004
A9	Mainshaft Reverse Gear	1252 3052	13-86-088-003
A10	Mainshaft Reverse Gear Bearing	1252 3050	13-86-132-003
A11	Mainshaft Reverse Gear Wave Spring	1252 3048	13-86-156-005
A12	Mainshaft Reverse Gear Thrust Washer	1252 3047	13-86-193-005
A13	Mainshaft Reverse Synchronizer Assy	1252 3253	13-86-139-001
A14	Mainshaft Reverse Synchronizer Ring	1252 3049	13-86-091-007

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

A15	Mainshaft Reverse Synchronizer Assy	1252 3043	13-86-590-004
A15-3	Strut	1408 3521	13-51-093-001
A15-4	Spring	1252 3251	13-86-156-002
A15-5	Strut Retainer	1252 3044	13-86-040-002
A16	Mainshaft 5th/6th Cluster	1252 3041	13-86-070-001
A16	Mainshaft 5th/6th Cluster	1252 3042	13-86-070-002
A17	Mainshaft 5th/6th O-Ring		13-00-141-028
A18	Mainshaft Bearing Assy	1252 3286	25520-72
A18-1	Mainshaft Bearing Cup		25520
A18-2	Mainshaft Bearing Cone		25572
A19	Mainshaft 1st Gear	1252 3199	13-86-081-005
A19	Mainshaft 1st Gear	1252 3200	13-86-081-006
A19	Mainshaft 1st Gear	1252 3201	13-86-081-007
A19	Mainshaft 1st Gear	1245 5013	13-86-081-008
A19	Mainshaft 1st Gear	8889 4089	TUEN 1122
A20	Mainshaft 1st Gear Bearing	1252 3188	13-86-132-002
A21	Mainshaft 1st Gear Spacer	1245 5012	13-86-053-005
A22	Mainshaft 1st/2nd Synchronizer Snapping	1252 3187	13-00-139-015
A23	Mainshaft 1st/2nd Synchronizer T'Washer	1252 3198	13-86-193-002
A24	Mainshaft 1st/2nd Synchronizer Assy	1252 3191	U TNKT1873
A24	Mainshaft 1st/2nd Synchronizer Assy	1245 5006	13-86-590-008
A24-3	Strut	1252 3192	13-86-093-001
A24-3	Strut	1245 5007	13-86-093-002
A24-4	Spring	1252 3193	13-86-156-001
A24-4	Spring	1245 5008	13-86-156-013
A25	Mainshaft 1st/2nd Synchro Ring (Outer)	1252 3194	13-86-091-001
A25	Mainshaft 1st/2nd Synchro Ring (Outer)	1245 5009	13-86-091-008
A26	Mainshaft 1st/2nd Synchro Ring (Center)		TUAS 1365
A26	Mainshaft 1st/2nd Synchro Ring (Center)	1245 3259	13-81-525-001
A26	Mainshaft 1st/2nd Synchro Ring (Center)	8889 4073	TUAS 1127
A27	Mainshaft 1st/2nd Synchro Ring (Inner)	1252 3195	13-86-025-001
A27	Mainshaft 1st/2nd Synchro Ring (Inner)	8889 4072	TUAS 1128
A28	Mainshaft 2nd Gear	1252 3189	13-86-082-004
A28	Mainshaft 2nd Gear	1252 3190	13-86-082-005
A28	Mainshaft 2nd Gear	1245 5004	13-86-082-006
A28	Mainshaft 2nd Gear	8889 4088	TUEN 1123
A29	Mainshaft 2nd Gear Bearing	1252 3073	13-00-132-009
A30	Mainshaft 2nd Gear Bearing Spacer	1245 5005	13-86-053-006
A31	Mainshaft 3rd Gear	1252 3075	13-86-083-005

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

A31	Mainshaft 3rd Gear	1252 3076	13-86-083-006
A31	Mainshaft 3rd Gear	1252 3077	13-86-083-007
A31	Mainshaft 3rd Gear	8889 4114	13-86-083-008
A31	Mainshaft 3rd Gear	8889 4087	TUEN 1124
A32	Mainshaft 3rd Gear Bearing	1252 3073	13-00-132-009
A33	Mainshaft 3rd Gear Bearing Spacer	1252 3074	13-86-053-003
A33	Mainshaft 3rd Gear Bearing Washer	1245 5005	13-86-193-010
A34	Mainshaft 3rd Synchro Ring (Outer)	1245 5000	13-86-091-009
A35	Mainshaft 3rd Synchro Ring (Center)	8889 4069	TUAS 1129
A36	Mainshaft 3rd Synchro Ring (Inner)	1245 4999	13-86-025-002
A37	Mainshaft 3rd/4th Synchronizer Assy	1252 3078	13-86-590-002
A37	Mainshaft 3rd/4th Synchronizer Assy	1245 5002	13-86-590-006
A37-3	Strut	1408 3521	13-51-093-001
A37-4	Spring	1252 3185	13-86-156-003
A38	Mainshaft 3rd/4th Synchronizer Ring	1252 3186	13-86-591-003
A38	Mainshaft 3rd/4th Synchronizer Ring		13-81-591-001
A38	Mainshaft 4th Synchro Ring (Outer)	1245 5018	13-86-091-011
A39	Mainshaft 4th Synchro Ring (Center)	8889 4070	TUAS 1126
A40	Mainshaft 4th Synchro Ring (Inner)	1245 5017	13-86-025-003
A41	Mainshaft 3rd/4th Synchronizer Washer	1245 5003	13-86-193-011
A42	Mainshaft 3rd/4th Synchronizer Snapping	1252 3187	13-00-139-015
A42	Mainshaft 3rd/4th Synchronizer Snapping	1252 3253	13-86-139-001
A43	Mainshaft	1252 3072	13-86-171-003
A43	Mainshaft	1245 4996	13-86-171-007
A44	Extension Assy	1252 3276	13-86-566-009
A44	Extension Assy		13-86-566-016
A44	Final Drive Adapter (Extension) Assy	1245 5042	13-86-566-019
A44	Extension Assy		13-86-566-024
A44-2	Mainshaft Bushing		R10H-77
A44-2	Mainshaft Oilseal (Inner)	1245 5044	13-00-044-022
A44-3	Selector Rail Bushing	1252 3001	13-86-127-001
A44-3	Mainshaft Oilseal (Outer)	1245 5045	13-00-044-024
A44-4	Drain Plug	1252 3308	19-00-052-008
A44-5	Stud	1245 5043	13-86-146-003
A45	Mainshaft Oilseal	1011 7848	13-00-044-013
A46	Final Drive Adapter Fasteners	1245 8099	
A46	Final Drive Adapter Fasteners	1252 3235	13-86-183-001
A46	Extension Fasteners (Bumper)	1252 4483	13-86-168-001
A47	Drain Plug	1252 3308	19-00-052-008

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

B1	Mainshaft Pilot Bearing Cone		LM12749
B1	Mainshaft Pilot Bearing Cone	889 4093	LM12749
B2	Maindrive Gear Assy	1252 3214	13-86-585-003
B2	Maindrive Gear Assy	1252 3215	13-86-585-005
B2	Maindrive Gear Assy		13-86-585-007
B2	Maindrive Gear Assy	8889 4115	13-86-585-009
B2	Maindrive Gear Assy	1245 3260	13-86-585-010
B2	Maindrive Gear Assy	8889 4050	TUEF 1218
B2-2	Mainshaft Pilot Bearing Cup	8889 4092	LM12711
B2-2	Mainshaft Pilot Bearing Cup		LM12711
B3	Maindrive Bearing Assy	1252 3289	M88010-48
B3-1	Maindrive Bearing Cup		M88010
B3-2	Maindrive Bearing Cone		M88048
B4	Maindrive Bearing Shim	NSS	U SH56
B5	Clutch Housing Adapter Assy	1252 3036	13-86-672-001
B5	Clutch Housing Adapter Assy	1252 3037	13-86-672-003
B5	Front Cover Assy		13-86-672-006
B5	Front Cover Assy	1245 5019	13-86-672-007
B5	Clutch Housing Adapter Assy		13-86-672-008
B5-2	Shift Rail Bushing	1252 3001	13-86-127-001
B5-3	Clutch Release Bearing Tube		13-86-034-001
B5-4	Clutch Release Bearing Tube O-Ring		13-00-141-034
B5-5	Maindrive Oilseal	1563 5337	13-00-044-015
B5-6	Cover/Case Dowel Pin	1252 3068	141199
B5-7	Adapter/Clutch Housing Dowel Pin		13-00-043-009
B5-8	Selector Rail Oilseal (Inner)	1245 5028	13-00-044-021
B5-9	Selector Rail Oilseal (Outer)	1245 5027	13-86-044-001
B6	Front Cover Inspection Plug	1252 3306	19-00-052-008
B7	Front Cover Fasteners	1252 3235	13-86-183-001
B8	Clutch Release Fork Assy	1252 3312	13-86-596-004
B9	Clutch Release Fork Pivot	1252 3314	13-86-183-004
B10	Clutch Release Fork Pivot Nut	1252 3313	13-86-149-001
B11	Clutch Housing (Assy)	1252 3310	13-86-712-001
B11	Clutch Housing (Assy)		13-86-212-005
B11-2	Slave Cylinder Studs		13-86-146-002
B12	Clutch Housing Fasteners	1252 3235	13-86-183-001
B13	Clutch Slave Cylinder Adapter		13-86-172-002
B14	Clutch Housing Adapter		13-86-172-008
B15	Clutch Housing Adapter Fasteners		13-00-183-014

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

B16	Maindrive Retainer		13-52-027-007
B17	Maindrive Retainer Fasteners		13-00-183-036
C1	Countershaft Extension Oil Funnel	1252 3275	13-86-034-002
C2	Countershaft Extension Bearing Shims	NSS	U SH56
C3	Countershaft Extension Bearing Assy	1252 3059	LM12711-49
C3-1	Countershaft Extension Bearing Cup	8889 4092	LM12711
C3-2	Countershaft Extension Bearing Cone	8889 4093	LM12749
C4	Countershaft Extension		13-86-077-007
C4	Countershaft Extension Shaft		13-86-077-009
C5	Countershaft 5th Gear	1252 3248	13-86-086-003
C5	Countershaft 5th Gear	1252 3249	13-86-086-004
C5	Countershaft 5th Gear	1245 5034	13-86-086-005
C6	Countershaft 5th Gear Bearing	1252 3247	10-00-132-046
C7	Countershaft 5th/6th Synchronizer Assy		13-86-590-003
C7	Countershaft 5th/6th Synchronizer Assy	1245 5035	13-86-590-007
C7-3	Strut	1408 3521	13-51-093-001
C7-4	Spring	1252 3251	13-86-156-002
C8	Countershaft 5th/6th Synchro Ring (Outer)	1245 5036	13-86-091-010
C8	Countershaft 5th/6th Synchro Ring	1252 3252	13-86-591-005
C9	Countershaft 5th/6th Synchro Ring (Center)	8889 4070	TUAS 1126
C10	Countershaft 5th/6th Synchro Ring (Inner)	1245 5017	13-86-025-003
C11	Countershaft 5th/6th Synchronizer Washer	1245 5039	13-86-193-012
C12	Countershaft 5th/6th Synchronizer Snapping	1252 3253	13-86-139-001
C13	Countershaft 6th Gear	1252 3256	13-86-087-003
C13	Countershaft 6th Gear	1252 3257	13-86-087-004
C13	Countershaft 6th Gear	1245 5041	13-86-087-005
C14	Countershaft 6th Gear Bearing Spacer	1252 3254	13-86-053-001
C15	Countershaft 6th Gear Bearing	1245 3255	13-86-132-005
C16	Countershaft 6th Gear Thrust Washer	12523038	13-86-193-008
C16	Countershaft 6th Gear Bearing Spacer	1245 5040	13-86-053-007
C16	Countershaft 6th Bearing Bearing Spacer	1252 3056	13-86-193-006
C17	Countershaft Rear Bearing Assy	8889 4091	
C17-1	Countershaft Rear Bearing Cup		13-86-133-001
C17-2	Countershaft Rear Bearing Cone		13-86-133-002
C18	Countershaft Cluster Gear		13-86-077-005
C18	Countershaft Cluster Gear		13-86-077-008
C18	Countershaft Cluster Gear		13-86-077-006
C19	Countershaft Front Bearing Assy	8889 4090	

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

C19	Countershaft Front Bearing Assy		LM48510-48
C19-1	Countershaft Front Bearing Cup		LM48510
C19-2	Countershaft Front Bearing Cone		LM48548
C20	Countershaft Front Bearing Shims	NSS	U SH56
C21	Idler Gear	1252 3283	13-86-084-001
C22	Idler Gear Bearing	1252 3284	13-86-132-006
C23	Idler Gear Thrust Washer	1252 3285	13-86-193-003
C24	Idler Shaft		13-86-068-001
C24	Idler Shaft	1236 9469	13-86-068-002
C25	Idler Shaft Support	1252 3287	13-86-185-001
C25	Idler Shaft Support	1236 9470	13-86-185-002
C26	Idler Shaft Support Fasteners	1252 3243	13-86-183-002
C27	Case Assy	1252 3066	13-86-565-002
C27	Case Assy	1252 3067	13-86-565-005
C27-2	Shift Rail Bushing	1252 3001	13-86-127-001
C27-3	Dowel Pin	1252 3068	141199
C28	Magnet	1238 6078	4915
C29	Breather Elbow		13-00-072-003
C29	Breather Elbow	1252 3294	13-00-072-004
C30	Breather Tube Assy		13-86-572-001
C30	Breather Tube Assy	1245 5049	
C30-1	Breather Tube and Vent		13-86-572-002
C30-2	Breather Tube Fasteners	1245 5047	13-00-056-010
C31	Fill Plug	1252 3308	13-00-052-007
C31	Fill Plug	1238 7621	
D1	1st/2nd Shift Fork Assy	1252 3210	13-86-596-013
D1-2	1st/2nd Shift Fork Pads	1252 3208	13-86-235-001
D2	1st/2nd Shift Lugplate	1252 3209	13-86-190-001
D3	Selector Rail	1252 3206	13-86-100-007
D3	Selector Rail		13-86-100-012
D3	Selector Rail	1245 5014	13-86-100-013
D4	Selector Finger Assy	1252 3211	13-86-596-011
D5	Selector Finger Rollpin	454512	13-32-043-004
D6	Interlock Bushing	1252 3212	13-86-014-007
D7	Interlock Bushing Guide (Bolt)	1252 3213	13-86-183-003
D8	3rd/4th Shift Fork Assy	8899 6653	TNEC 0843
D8-2	3rd/4th Shift Fork Pad	1252 3208	13-86-235-001
D9	3rd/4th Shift Lugplate	1252 3209	13-86-190-001

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

D10	5th/6th Shift Fork Snapping	1254 1299	13-00-139-001
D11	5th/6th Shift Fork Assy	1252 3258	13-86-596-003
D11-2	5th/6th Shift Fork Pad	1252 3233	13-86-235-002
D12	Reverse Shift Fork Snapping	1252 3055	13-86-139-004
D13	Reverse Shift Fork Assy	1252 3288	13-86-596-009
D13-2	Reverse Shift Fork Pad	1252 3233	13-86-235-002
D14	Reverse Shift Rail Assy		13-86-600-001
D14-1	5th/6th Shift Lug Assy	1252 3204	13-86-598-020
D14-1B	5th/6th Shift Lug Pad	1252 3233	13-86-235-002
D14-1C	5th/6th Shift Lug Bushing	1252 3001	13-86-127-001
D14-2	Reverse Shift Lug	1252 3205	13-86-098-010
D14-3	Reverse Shift Lug Rollpin	454512	13-32-043-004
D14-4	Reverse Shift Rail	1252 3202	13-86-100-004
D14-5	Reverse Shift Stop	1252 3203	13-86-103-003
D14-6	Reverse Shift Stop Rollpin	454512	13-32-043-004
D15	5th/6th Shift Lug Guide (Bolt)	1252 3213	13-86-183-003
D16	Skipshift Lever	1253 4782	13-86-098-023
D17	Skipshift Lever Rollpin	454512	13-32-043-004
D18	Detent Lever	1252 3241	13-86-098-022
D18	Detent Lever	1245 5033	13-86-098-024
D18	Detent Lever		13-86-098-025
D19	Detent Lever Rollpin	454512	13-32-043-004
D20	Vertical Detent Spring		13-86-156-001
D20	Vertical Detent Spring	1252 3242	13-86-156-004
D21	Vertical Detent Ball	7826284	13-00-109-003
D22	Shift Pattern Guide	1252 3236	13-86-014-008
D23	Shift Pattern Guide Fasteners	1252 3243	13-86-183-002
D24	Shift Pattern Access Cover		13-86-039-001
D24	Shift Pattern Access Cover	1245 5046	13-86-039-002
D25	Shift Pattern Access Cover Fasteners	1245 5048	13-00-183-034
D25	Shift Pattern Access Cover Fasteners	1554 6805	13-51-183-001
D26	Neutral Bias Cam	1245 5029	13-86-099-001
D27	Neutral Bias Cam Pin	1245 5030	13-00-043-016
D28	Neutral Bias Cam Spring	8899 6654	13-86-156-014
D29	Neutral Bias Cam Fasteners (Washers)	1245 5032	13-52-193-008
D29	Neutral Bias Cam Fasteners (Bolt)	1554 6805	13-51-183-001
D30	Offset Lever		13-86-098-016
D31	Offset Lever Bushing	1410 5942	13-52-127-009
D32	Offset Lever Rollpin	454512	13-32-043-004

For prices please contact Auto Gear Company at 1-800-634-3001

**AUTO GEAR Parts for WARNER GEAR T56 Six Speed
End User Pricing
Effective Date: February 1 2005**

D33	Shift Lever Assy (Lower)	1021 5351	13-86-598-023
D33	Lower Shift Lever Assy		13-86-598-031
D33	Shift Lever Assy (Lower)		13-86-598-032
D34	Shift Lever Fasteners	1554 6805	13-51-183-001
D34	Shift Lever Fasteners		13-00-183-034
D35	Upper Shift Lever		13-86-598-026
D36	Upper Shift Lever Fasteners		13-00-183-035
D37	Shift Lever Boot		13-86-021-001
E1	Skipshift Solenoid Assy	1252 3292	13-86-640-007
E1-2	Skipshift Solenoid O-Ring	1252 3293	13-86-141-117
E2	Horizontal Detent Assy		13-86-608-005
E2	Horizontal Detent Assy	1245 5056	13-86-608-006
E3	Reverse Lockout Assy	1252 3299	13-86-640-002
E3-2	Reverse Lockout Housing O-Ring	1252 3301	13-00-141-120
E3-3	Reverse Lockout Solenoid Assy	1252 3300	13-86-640-008
E2-3B	Reverse Lockout Solenoid O-Ring	1252 3293	13-00-141-117
E4	Reverse Lockout Fasteners	1252 3302	13-00-183-009
E5	Reverse Indicator Switch	1406 9600	10-00-140-013
E6	Oil Temperature Sensor	1245 8118	13-00-140-013
E7	Speedometer Sensor Assy	1252 3306	13-86-140-006

For prices please contact Auto Gear Company at 1-800-634-3001